

SERVICE MANUAL

Table of contents

1. General information.....	3
1.1 Getting start.....	3
1.2 Basic topology introduction.....	3
1.3 Inverter family.....	4
1.4 Overview the inverter.....	5
1.5 PCB overview.....	6
2. Troubleshooting	8
2.1 How to do.....	8
2.2 Check the fault information	8
2.3 Fault condition.....	8
2.4 Test step.....	9
3. Checking and measuring guide.....	10
3.1 Check the battery side components	10
3.2 Check the bus side components	18
3.3 Check the buck circuit.....	19
3.4 Check the INV full bridge	20
3.5 Check the MPPT SCC board.....	24
4. Disassembling guide	25
4.1 Open the case.....	25
4.2 Remove the control board.....	26
4.3 Remove the fan paper and the MPPT board.....	28
4.4 Remove the main board	30
5. Cables connection.....	33

SERVICE MANUAL

1. General information

1.1 Getting start

This manual is used as a checking and repairing guide for **0.7~3KW-120V** model. Before read this manual, it's better to have some electrical or electronic background knowledge. With this guide, you can fix the inverter by yourself firstly.

There are five main parts of this guide:

General information: This part is the basic information of the inverter; you can start to know the inverter from this chapter.

Troubleshooting: This part will tell you how to do when you face a problem.


Checking and measuring guide: This part will teach you how to check or repair the inverter by measuring the critical components.

Assembling guide: This part teaches you how to take the board outside and fix the new one.

Cables connection: This part is a reference for cable connection.

1.2 Basic topology introduction

The topology of the inverter shows as below:



Compare with UPS or normal inverter, INVERTER combines a solar charger inside. Solar charger can be a supplement for battery when there is not grid or for saving energy purpose. And with the solar charger, the inverter can have more working modes than UPS. For detail information please refer to our user manual.

SERVICE MANUAL

1.3 Inverter family


This service manual includes different models of the inverter, the table as below contains some important parameters with different models.

These models names are only neutral names; please match the real model name of your inverter to the model name in the table by comparing the typical characteristics.

Model name	Power rating	Solar charger type	Solar charger number	Off-grid/Hybrid
INVERTER 3KW	3KW	MPPT	1	Off-grid
INVERTER 2.6KW	2.6KW	MPPT	1	Off-grid
INVERTER 2KW	2KW	MPPT	1	Off-grid
INVERTER 1.4KW	1.4KW	MPPT	1	Off-grid
INVERTER 1KW	1KW	MPPT	1	Off-grid
INVERTER 0.7KW	0.7KW	MPPT	1	Off-grid

SERVICE MANUAL


1.4 Overview the inverter




SERVICE MANUAL

1.5 PCB overview

Main board:




Control board:



SERVICE MANUAL

MPPT board:



SERVICE MANUAL

2. Troubleshooting

2.1 How to do

When the inverter was faulty, normally there are two main symptoms:

- No display at all;
- Fault code or warning code on the LCD;

When the fault occurred, please help to record the fault information and follow “How to check” of part 2.3 to check the inverter, then feedback the checking result to the service center. It will be very helpful for solving the problem as soon as possible.

2.2 Check the fault information

Please follow the steps as below to find the issues!

Make sure that you can finish all the steps and feedback us the results. Or we may not be able to give you the right solution.

Step 1: Test the battery working mode.

Before turning on the inverter, only connect the battery with the inverter which means no solar input and grid input. Turn on the switch, the LCD will light up and wait for the battery connecting to load.

If the connection is failed, please record the fault code.

Step 2: Test the grid charging mode.

Before turning on the inverter, only connect the utility and battery with the inverter. Without press any buttons, the LCD will light up. And wait for the utility connecting to battery.

If the connection is failed, please record the fault code.

Step 3: Test the solar charging mode.

Before turning on the inverter, only connect the solar and battery with the inverter. Without press any buttons, the LCD will light up. And wait for the solar connecting to battery.

If the connection is failed, please record the fault code.

2.3 Fault condition

Note:

When open the top cover, please have a look first, are there any obviously damaged parts?
When take the main board out, please have a look around, are there any obviously damaged parts?

2.2.1. Not working at all/ No display

Description	The inverter couldn't startup completely.
Possible reason	1. SPS module damaged.
How to check	1. Firstly, please measure the resistor between BAT+ and BAT-. If it is not shorted, only connect the inverter with battery, and press “ON” button, could the inverter startup? If not, please check the fan. 2. If the LCD couldn't light up and fan doesn't work, please disconnect all the wires and open the top cover, and then take the main board outside by following part 4.
How to solve	Replace the main board.

2.2.2. 08 fault

SERVICE MANUAL

Description	Bus voltage is too high
Possible reason	Firmware bug.
How to check	Restart the inverter, will the fault repeat?
How to solve	Update the firmware

2.2.3. 09 fault

Description	Bus soft start fails.
Possible reason	DC-DC module was damaged.
How to check	Check the main board by following “3.1~3.4”;
How to solve	Repair the main board or replace it directly.

2.2.4. 56 fault

Description	Battery couldn't be detected.
Possible reason	Wire connection or fuse was burnt.
How to check	1. Check the wire connection, the priority of the battery cable; 2. Check the main board by following “3.1”.
How to solve	Repair the main board or replace it directly.

2.2.5. 72 fault

Description	Current sensor is abnormal.
Possible reason	The control board was damaged.
How to check	Check the control board by following “3.9”.
How to solve	Replace the control board.

2.2.6. No solar input


Description	The inverter couldn't detect the solar input.
Possible reason	SCC board issues
How to check	<p>Please use the multimeter measure the solar input voltage?</p> <p>1. If the voltage is 0V, please disconnect the solar input, and measure the voltage of two polarities of the solar panels again. After disconnection, if the solar voltage is more than 60V, it means that the solar input is shorted. Please refer to SCC board checking guide about power device part*.</p> <p>2. If the voltage is the real solar panels voltage, but no solar display. It means that the SCC board didn't wake up. Please refer to SCC board checking guide about SPS part*.</p>
How to solve	Repair the board or replace it.

2.4 Test step

After replacing all defected components, testing steps can be used to confirm the repair result and the reliability of the Inverter.

Set up the testing system as below:

SERVICE MANUAL




SERVICE MANUAL

3. Checking and measuring guide

3.1 Check the battery side components


Fuse and capacitors

F3



Parts	Attribute	Reference values	Failure status
F3	Resistor	0 ohm	Open

C9/C13/C8/C12




If the capacitors explode as below, they need to be replaced.



SERVICE MANUAL

Power devices

DC/DC MOSFET: Q13/Q18/Q23 & Q11/Q17/Q20 & Q21/Q22/Q12 & Q26/Q25/Q14



Parts	Attribute	Reference values	Failure status
All:	Resistor ¹	GS: 11.7K GD: 250K DS: 0.55M	Short or explosion
	Diode	SD: 0.43V DS: OL	

Note1: When you use the multimeter to measure the resistor of the transistor, because of the capacitor in the circuit, it will cause the changing of the values when you measure the DS and GD. So we recommend you measure the diode forward voltage of SD, and the resistor of GS. These two values can reflect the situation of the transistor more correctly.

Note: If one or more of them were damaged, please replace all of them.

3.1.1. Drivers (This part is only used for repair checking)


Note: Drivers usually need to be checked when users want to repair the boards. Because when power devices were damaged, the high voltage will rush to driver circuit through the gates of power devices.

The reference of the resistors list as below:

R41/R59/R70/R76/R80/R78/R75/R42/R52/R62/R81/R64/R93/R92/R87/R53

TVS2/ TVS3/ TVS6/ TVS7/ TVS10/ TVS11 / TVS14/ TVS15


SERVICE MANUAL



Use multimeter to measure each resistor, find the burnt resistors and replace them; don't need to replace them all.

Parts	Attribute	Reference values	Failure status
All: 33ohm	Resistor	33 ohm	Open or other values
TVS2-15	Diode	+ To - : 0.42V	Short or explosion


If the resistors need to be replaced, please also check the driver transistors and control IC.



The Q46and Q48 are 11-300012-00G (TR 2A 50V NPN TO-92)

The Q47and Q49 are 11-300005-00G (TR 2A 50V PNP TO-92NL)

SERVICE MANUAL




The Q41 and Q43 are 11-300012-00G (TR 2A 50V NPN TO-92)

The Q15 and Q16 are 11-300005-00G (TR 2A 50V PNP TO-92NL)


Parts	Attribute	Reference values	Failure status
Q46/Q48/Q41/Q43	Resistor	BE: 434.2k BC: 429.3k CE: 19.52k	Short or explosion
	Diode	BE: 0.656V BC: 0.655V CE: 1.3V	
Q47/Q49/Q15/Q16	Resistor	BE: 433.5k BC: 432.1k CE: 8.1k	Short or explosion
	Diode	BE: 0.656V BC: 1.741V CE: 0.2V	

SERVICE MANUAL



The Q54and Q56 are 11-400011-00G (TR 2A 50V NPN SOT-89)

The Q55and Q57 are 11-400010-00G (TR 3A 50V PNP SOT-89)



The Q51and Q52 are 11-400011-00G (TR 2A 50V NPN SOT-89)

The Q50and Q53 are 11-400010-00G (TR 3A 50V PNP SOT-89)

Parts	Attribute	Reference values	Failure status
Q54/Q56/Q51/Q52	Resistor	BE: 12k BC: 263.5K CE: OL	Short or explosion
	Diode	BE: 0.632V BC: 0.631V CE: OL	
Q55/Q57/Q50/Q53	Resistor	BE: 12k BC: OL CE: 277.3k	Short or explosion


SERVICE MANUAL

Diode

BE: 0.632V


BC: OL

CE: 1.107V



The Q60 and Q61 are 11-420007-00G (MOSFET 5.8A 30V SOT-23)

Parts	Attribute	Reference values	Failure status
Q60/Q61	Resistor	GS: 4.185k GD: 12.08k DS: 90k	Short or explosion
	Diode	SD: 0.207V DS: 1.274V	



Parts	Attribute	Reference values	Failure status
U9	Resistor	Pin13TOPin12:100~300k Pin11TOPin12: 438k	Short or explosion

SERVICE MANUAL


Pin14 TO PIN12: 438k

Note: If you are not sure about these components, we recommend you replacing them all.

3.2 Check the bus side components

Power devices

DC/DC IGBT: Q30/Q29/Q27/Q28



Parts	Attribute	Reference values	Failure status
Q27/Q28/Q29/Q30	Resistor ¹	GE: 47.8 ohm GC:169.46k CE:400-500K	Short or explosion
	Diode	EC: 0.36V CE: OL	


Note1: When you use the multimeter to measure the resistor of the transistor, because of the capacitor in the circuit, it will cause the changing of the values when you measure the CE and GE. So we recommend you measure the diode forward voltage of EC, and the resistor of GE. These two values can reflect the situation of the transistor more correctly.

Note: If one or more of them were damaged, please replace all of them.

SERVICE MANUAL

Drivers (This part is only used for repair checking)

Meanwhile, we also need to check the driver tubes of these power tubes.




Parts	Attribute	Reference values	Failure status
R91/R102/R96/R101	Resistor	47 ohm	Open or other values
Note2: When test the diode; please remove the R90/R99/R94/R97 from the board, or the test result is not right.			

3.3 Check the buck circuit

Power devices

BUCK MOSFET and Diode:Q32 / D13




Parts	Attribute	Reference values	Failure status
Q32	Resistor	GE: 22.7 K GC: 232K CE: 1-20M	Short or explosion

SERVICE MANUAL

	Diode	SD or CE: 0.381V DS or EC: OL	
D13	Resistor	+ to -: 25.7K - to +: OL	
	Diode	+ to -: 0.39V - to +: OL	

Drivers (This part is only used for repair checking)




Parts	Attribute	Reference values	Failure status
R125	Resistor	47 ohm	Open or other values

Note: When test the diode; please remove the R124 from the board, otherwise the test result is not right.

Check the INV full bridge

Power devices

INV IGBT: QB2/QD2/QA1/QC1/QD4/QD3




Parts	Attribute	Reference values	Failure status
-------	-----------	------------------	----------------

SERVICE MANUAL

QB2/QD2/QA1/QC1/QD4/QD3	Resistor	GE: 45.46K GC: 250k CE: 38M	Short or explosion
	Diode	EC: 0.38V CE: OL	


Note1: If one or more of them were damaged, please replace all of them.

Drivers



Parts	Attribute	Reference values	Failure status
R144/R48/R140/R137	Resistor	47 ohm	Open or other values
R151/R189	Resistor	22 ohm	Open or other values

Optocoupler: U1/U2/U3/U4/ U6/U11/U12




Parts	Attribute	Reference values	Failure status
U1/U2/U3/U4/ U6/U11/U12	Resistor	PIN8 TO PIN5: 0.922M PIN7 TO PIN5: 0.953M	Short or explosion

SERVICE MANUAL

3.4 Check the MPPT board (PCB Version: 16-500483-XXG)

Power devices




Parts	Attribute	Reference values	Failure status
Q2,Q3,Q4,Q10,Q11,Q13	Resistor	GS: 5k GD: 36K DS: OL	Short or explosion
	Diode	SD: 0.445V DS: OL	
D24,D47,D48,D49	Resistor	+ to -: 0.86k - to +: OL	Short or explosion
	Diode	+ to -: 0.144V - to +: OL	
Q16	Resistor	GS: 46.8K GD: 404K DS: OL	Short or explosion

SERVICE MANUAL

	Diode	SD: 0.534V DS: OL	
--	-------	----------------------	--

Driver




Parts	Attribute	Reference values	Failure status
U14, U15	Resistor	PIN4 TO PIN2: 2.8k PIN1 TO PIN7: 4.8k	Short or explosion

4. Disassembling guide

4.1 Open the case

Remove screws on the top cover	
--------------------------------	--

SERVICE MANUAL



SERVICE MANUAL




SERVICE MANUAL

Open the top cover carefully, for there are two cables connected with LCD display.




4.2 Remove the control board

Remove the cables on the control board.




SERVICE MANUAL

Remove the fixing screws.



Take out the control board.




Note: When you put the new control board on the main board, please make sure that the connection is correct and tighten. Don't forget to put the screws and cables back.

SERVICE MANUAL


4.3 Remove the fan paper and the MPPT board.

1. Take the plastic screws out.
2. Take two nuts out.
3. you can take the fan paper off.



SERVICE MANUAL

Remove the screws and the signal cables of the MPPT board , and you can take the MPPT board paper off.




4.4 Remove the main board.

Note: Before replace the main board, please follow 4.2 ~ 4.4, remove the control board, MPPT board, and fans first.


SERVICE MANUAL

Remove the power cables of AC output and input.
Brown cable is line;
blue cable is neutral.
Do not make the
wrong polarity.




SERVICE MANUAL

Remove the fans cables.



Remove the screws and the signal cables on the main board. And then you can take the main board out.

Note: There are nine screws to fix the main board.



SERVICE MANUAL

5. Cables connection

