

PIP-HS/MS/MSX & HYBRID V Communication Protocol


1	Message format	2
2	Inquiry Command	2
2.1	QID<cr>: The inverter serial number inquiry.....	2
2.2	QSID<cr>: The inverter serial number inquiry (the length is more than 14).....	2
2.3	QVFW<cr>: Main CPU firmware version inquiry	2
2.4	QVFW2<cr> :Another CPU firmware version inquiry	2
2.5	QPIRI<cr>: Inverter rated information inquiry	2
2.6	QFLAG<cr>: Inverter flag status inquiry.....	4
2.7	QPIGS<cr>: Inverter general status parameters inquiry.....	5
2.8	QPGSn<cr>: Parallel Information inquiry (For 4K/5K)	6
2.9	QMOD<cr>: Inverter Mode inquiry.....	9
2.10	QPIWS<cr>: Inverter Warning Status inquiry	9
2.11	QDI<cr>: The default setting value information	11
2.12	QMCHGCR<cr>: Enquiry selectable value about max charging current.....	13
2.13	QMUCHGCR<cr>: Enquiry selectable value about max utility charging current.....	14
2.14	QOPM<cr>: Enquiry output mode (For 4000/5000).....	14
3	Setting parameters Command	14
3.1	PE<XXX>/PD<XXX><CRC><cr>: setting some status enable/disable.....	14
3.2	PF<cr>: Setting control parameter to default value.....	14
3.3	MCHGC<nnn><cr>: Setting max charging current.....	16
3.4	MNCHGC<mnnn><cr>: Setting max charging current (More than 100A)	16
3.5	MUCHGC<nnn><cr>: Setting utility max charging current.....	17
3.6	F<nn><cr>: Setting Inverter output rating frequency.....	17
3.7	POP<NN><cr>: Setting Inverter output source priority	17
3.8	PBCV<nn.n><cr>: Set battery re-charge voltage.....	17
3.9	PBDV<nn.n><cr>: Set battery re-discharge voltage.....	17
3.10	PCP<NN><cr>: Setting Inverter charger priority	18
3.11	PGR<NN><cr>: Setting Inverter grid working range	18
3.12	PBT<NN><cr>: Setting battery type	18
3.13	POPM<nn ><cr>: Set output mode (For 4000/5000)	18
3.14	PPCP<MNN><cr>: Setting parallel Inverter charger priority (For 4000/5000)	18
3.15	PSDV<nn.n><cr>: Setting battery cut-off voltage (Battery under voltage).....	18

3.16	PCVV<nn.n><cr>: Setting battery C.V. (constant voltage) charging voltage.....	19
3.17	PBFT<nn.n><cr>: Setting battery float charging voltage	19
3.18	PPVOKC<n ><cr>: Setting PV OK condition	19
3.19	PSPB<n ><cr>: Setting Solar power balance.....	19
3.20	QMN<cr>: Query model name(Just for Hybrid V Series)	19
3.21	QGMN<cr>: Query general model name.....	20
3.22	PBEQE<n><cr>: Enable or disable battery equalization.....	20
3.23	PBEQT<nnn><cr>:Set battery equalization time	20
3.24	PBEQP<nnn><cr>:Set battery equalization period.....	21
3.25	PBEQV<nn.nn><cr>:Set battery equalization voltage	21
3.26	PBEQOT<nnn><cr>:Set battery equalization over time.....	21
3.27	PBEQA<n><cr>: Active or inactive battery equalization now	21
3.28	QBEQI<cr>: Battery equalization status parameters inquiry	21
3.29	PCVT<nnn><cr>: Setting max charging time at C.V stage (For 4000/5000, and 012, 013 model)....	22
4	<i>Appendix</i>	22
4.1	CRC calibration method	22

Communication Protocol

Hardware connection:


RS232 to RJ45 cable between computer and inverter



The connection between P1 and P2

P1	wire color	P2	Function
1	white and orange	2	TXD
2	blue	3	RXD
8	white and green	5	GND

USB A to USB B cable between computer and Inverter



Standard B

1 + D-
2
3
4 - D+

Standard A

1 +
2 D-
3 D+
4 -

Standard-A plug			Standard-B plug		
1	+	+5V	1	+	+5V
2	D-	Data-	2	D-	Data-
3	D+	Data+	3	D+	Data+
4	-	GND	4	-	GND

1 Message format

Baud rate	Start bit	Data bit	Parity bit	Stop bit
2400	1	8	N	1

2 Inquiry Command

2.1 QID<cr>: The inverter serial number inquiry

Computer: QID <CRC><cr>

Inverter: (XXXXXXXXXXXXXXXXX <CRC><cr>

2.2 QSID<cr>: The inverter serial number inquiry (the length is more than 14)

Computer: QSID<CRC><cr>

Inverter: (NNXXXXXXXXXXXXXXXXXXXXX <CRC><cr>

NN: Serial number valid length, X: Serial number, invalid part is filled as '0', total X is 20.

2.3 QVFW<cr>: Main CPU firmware version inquiry

Computer: QVFW<CRC><cr>

Inverter: (VERFW:<NNNNN.NN><CRC><cr>

<N> is a HEX number from 0...9 or A...F.

Example:

Computer: QVFW<CRC><cr>

Inverter: (VERFW:00123.01<CRC><cr>

00123: firmware series number; 01: version

2.4 QVFW2<cr> :Another CPU firmware version inquiry

Computer: QVFW2<CRC><cr>

UPS: (VERFW2: <NNNNN.NN><CRC><cr>

<N> is a HEX number from 0...9 or A...F.

2.5 QPIRI<cr>: Inverter rated information inquiry

Computer: QPIRI<CRC><cr>

Inverter: (BBB.B CC.C DDD.D EE.E FF.F HHHH IIII JJ.J KK.K JJ.J KK.K LL.L O PP QQO
O P Q R SS T U VV.V W X YYY<CRC><cr>

	Date	Description	Notes
A	(Start byte	
B	BBB.B	Grid rating voltage	B is an integer ranging from 0 to 9. The units is V.

Communication Protocol

C	CC.C	Grid rating current	C is an Integer ranging from 0 to 9. The units is A.
D	DDD.D	AC output rating voltage	D is an Integer ranging from 0 to 9. The units is V.
E	EE.E	AC output rating frequency	E is an Integer ranging from 0 to 9. The units is Hz.
F	FF.F	AC output rating current	F is an Integer ranging from 0 to 9. The unit is A.
H	HHHH	AC output rating apparent power	H is an Integer ranging from 0 to 9. The unit is VA.
I	III	AC output rating active power	I is an Integer ranging from 0 to 9. The unit is W.
J	JJ.J	Battery rating voltage	J is an Integer ranging from 0 to 9. The units is V.
K	KK.K	Battery re-charge voltage	K is an Integer ranging from 0 to 9. The units is V.
l	JJ.J	Battery under voltage	J is an Integer ranging from 0 to 9. The units is V.
M	KK.K	Battery bulk voltage	K is an Integer ranging from 0 to 9. The units is V.
N	LL.L	Battery float voltage	L is an Integer ranging from 0 to 9. The units is V.
O	O	Battery type	0: AGM 1: Flooded 2: User
P	PP	Current max AC charging current	P is an Integer ranging from 0 to 9 The units is A.
Q	QQ0	Current max charging current	Q is an Integer ranging from 0 to 9. The units is A.
O	O	Input voltage range	0: Appliance 1: UPS
P	P	Output source priority	0: Utility first 1: Solar first 2: SBU first
Q	Q	Charger source priority	0: Utility first 1: Solar first 2: Solar + Utility 3: Only solar charging permitted if battery voltage not too low
R	R	Parallel max number	R is an Integer ranging from 0 to 9.
S	SS	Machine type	00: Grid tie; 01: Off Grid; 10: Hybrid.

T	T	Topology	0: Transformerless 1: Transformer
U	U	Output mode	00: single machine output 01: parallel output 02: Phase 1 of 3 Phase output 03: Phase 2 of 3 Phase output 04: Phase 3 of 3 Phase output
V	VV.V	Battery re-discharge voltage	V is an Integer ranging from 0 to 9. The unit is V.
W	W	PV OK condition for parallel	0: As long as one unit of inverters has connect PV, parallel system will consider PV OK; 1: Only All of inverters have connect PV, parallel system will consider PV OK
X	X	PV power balance	0: PV input max current will be the max charged current; 1: PV input max power will be the sum of the max charged power and loads power.
Y	YYY	Max. charging time at C.V stage	Y is an Integer ranging from 0 to 9. The unit is minute.

2.6 QFLAG<cr>: Inverter flag status inquiry

ExxxDxxx is the flag status. E means enable, D means disable

x	Control setting
A	Enable/disable silence buzzer or open buzzer
B	Enable/Disable overload bypass function
J	Enable/Disable power saving
K	Enable/Disable LCD display escape to default page after 1min timeout
U	Enable/Disable overload restart
V	Enable/Disable over temperature restart
X	Enable/Disable backlight on
Y	Enable/Disable alarm on when primary source interrupt
Z	Enable/Disable fault code record

Computer: QFLAG <CRC><cr>

Inverter: (ExxxDxxx <CRC><cr>

2.7 QPIGS<cr>: Inverter general status parameters inquiry

Computer: QPIGS <CRC><cr>

Inverter: (BBB.B CC.C DDD.D EE.E FFFF GGGG HHH III JJ.JJ KKK OOO TTTT EEEE
UUU.U WW.WW PPPPP b7b6b5b4b3b2b1b0 QQ VV MMMMM b10b9b8<CRC><cr>

	Data	Description	Notes	Model
a	(Start byte		
b	BBB.B	Grid voltage	B is an Integer number 0 to 9. The units is V.	
C	CC.C	Grid frequency	C s an Integer number 0 to 9. The units is Hz.	
D	DDD.D	AC output voltage	D is an Integer number 0 to 9. The units is V.	
E	EE.E	AC output frequency	E is an Integer number from 0 to 9. The units is Hz.	
F	FFFF	AC output apparent power	F is an Integer number from 0 to 9. The units is VA	
G	GGGG	AC output active power	G is an Integer ranging from 0 to 9. The units is W.	
H	HHH	Output load percent	INVERTER: HHH is Maximum of W% or VA%. VA% is a percent of apparent power. W% is a percent of active power. The unit is %.	
I	III	BUS voltage	I is an Integer ranging from 0 to 9. The units is V.	
j	JJ.JJ	Battery voltage	J is an Integer ranging from 0 to 9. The units is V.	
k	KKK	Battery charging current	K is an Integer ranging from 0 to 9. The units is A.	
o	OOO	Battery capacity	X is an Integer ranging from 0 to 9. The units is %.	
P	TTTT	Inverter heat sink temperature	T is an integer ranging from 0 to 9. The units is °C (NTC A/D value for Inverter 1~3K)	
r	EEEE	PV Input current for battery.	E is an Integer ranging from 0 to 9. The units is A.	
t	UUU.U	PV Input voltage 1	U is an Integer ranging from 0 to 9. The units is V.	
u	WW.WW	Battery voltage from SCC	W is an Integer ranging from 0 to 9. The units is V.	
w	PPPPP	Battery discharge current	P is an Integer ranging from 0 to 9. The units is A.	
x	b7b6b5b4	Inverter status	b7: add SBU priority version, 1:yes,0:no	

	b3b2b1b0		b6: configuration status: 1: Change 0: unchanged b5: SCC firmware version 1: Updated 0: unchanged b4: Load status: 0: Load off 1: Load on b3: battery voltage to steady while charging b2: Charging status(Charging on/off) b1: Charging status(SCC charging on/off) b0: Charging status(AC charging on/off) b2b1b0: 000: Do nothing 110: Charging on with SCC charge on 101: Charging on with AC charge on 111: Charging on with SCC and AC charge on	
y	QQ	Battery voltage offset for fans on	Q is an Integer ranging from 0 to 9. The unit is 10mV.	
z	VV	EEPROM version	V is an Integer ranging from 0 to 9.	
	MMMM M	PV Charging power	M is an Integer ranging from 0 to 9. The unit is watt.	
	b10b9b8	Inverter status	b10: flag for charging to floating mode b9: Switch On b8: flag for dustproof installed(1-dustproof installed,0-no dustproof, only available for Hybrid V series)	

2.8 QPGSn<cr>: Parallel Information inquiry (For 4K/5K)

Computer: QPGSn<CRC><cr>

Inverter: (A BBBBBBBBBBBBBBBB C DD EEE.E FF.FF GGG.G HH.HH IIII JJJJ KKK LL.L MMM NNN OOO.O PPP QQQQQ RRRRR SSS b7b6b5b4b3b2b1b0 T U VVV WWW ZZ XX YYY<CRC><cr>















	Date	Description	Notes
A	(Start byte	
B	A	The parallel num whether exist	0: No exist. 1: Exist.
C	BBBBBBBBB BBBBBB	Serial number	B is an Integer ranging from 0 to 9.
D	C	Work mode	C is an character, refer to QMOD
E	DD	Fault code	D is an Integer ranging from 0 to 9.





Communication Protocol

F	EEE.E	Grid voltage	E is an Integer ranging from 0 to 9. The units is V.
G	FF.FF	Grid frequency	F is an Integer ranging from 0 to 9. The unit is Hz.
H	GGG.G	AC output voltage	G is an Integer ranging from 0 to 9. The units is V.
I	HH.HH	AC output frequency	H is an Integer ranging from 0 to 9. The unit is Hz.
J	III	AC output apparent power	I is an Integer number from 0 to 9. The units is VA
K	JJJ	AC output active power	J is an Integer ranging from 0 to 9. The units is W.
L	KKK	Load percentage	K is an Integer ranging from 0 to 9. The units is %.
M	LL.L	Battery voltage	L is an Integer ranging from 0 to 9. The unit is V.
N	MMM	Battery charging current	M is an Integer ranging from 0 to 9. The units is A.
O	NNN	Battery capacity	N is an Integer ranging from 0 to 9. The units is %.
P	OOO.O	PV Input Voltage	O is an Integer ranging from 0 to 9. The units is V.
Q	PPP	Total charging current	P is an Integer ranging from 0 to 9. The units is A.
R	QQQQQ	Total AC output apparent power	Q is an Integer ranging from 0 to 9. The units is VA.
S	RRRRR	Total output active power	R is an Integer ranging from 0 to 9. The units is W.
T	SSS	Total AC output percentage	S is an Integer ranging from 0 to 9. The units is %.
U	b7b6b5b4b3b2b1b0	Inverter Status	b7: 1 SCC OK, 0 SCC LOSS b6: 1 AC Charging 0 AC no charging b5: 1 SCC Charging 0 SCC no charging b4b3: 2 battery open, 1 battery under, 0 battery normal b2: 1 Line loss, 0 Line ok b1: 1 load on, 0 load off b0: configuration status: 1: Change 0: unchanged

Communication Protocol

V	T	Output mode	0: single machine 1: parallel output 2: Phase 1 of 3 phase output 3: Phase 2 of 3 phase output 4: Phase 3 of 3 phase output
W	U	Charger source priority	0: Utility first 1: Solar first 2: Solar + Utility 3: Solar only
X	VVV	Max charger current	V is an Integer ranging from 0 to 9. The units is A.
Y	WWW	Max charger range	W is an Integer ranging from 0 to 9. The units is A.
Z	ZZ	Max AC charger current	Z is an Integer ranging from 0 to 9. The units is A.
a	XX	PV input current for battery	X is an Integer ranging from 0 to 9. The units is A.
b	YYY	Battery discharge current	Y is an Integer ranging from 0 to 9. The units is A.

Fault Code	Fault Event	Icon on
01	Fan is locked	
02	Over temperature	
03	Battery voltage is too high	
04	Battery voltage is too low	
05	Output short circuited or Over temperature	
06	Output voltage is too high	
07	Over load time out	
08	Bus voltage is too high	
09	Bus soft start failed	
11	Main relay failed	
51	Over current inverter	
52	Bus soft start failed	
53	Inverter soft start failed	
54	Self-test failed	

55	Over DC voltage on output of inverter	
56	Battery connection is open	
57	Current sensor failed	
58	Output voltage is too low	
60	Inverter negative power	
71	Parallel version different	
72	Output circuit failed	
80	CAN communication failed	
81	Parallel host line lost	
82	Parallel synchronized signal lost	
83	Parallel battery voltage detect different	
84	Parallel Line voltage or frequency detect different	
85	Parallel Line input current unbalanced	
86	Parallel output setting different	

2.9 QMOD<cr>: Inverter Mode inquiry

Computer: QMOD<CRC><cr>

Inverter: (M<CRC><cr>

MODE	CODE(M)	Notes
Power On Mode	P	Power on mode
Standby Mode	S	Standby mode
Line Mode	L	Line Mode
Battery Mode	B	Battery mode
Fault Mode	F	Fault mode
Power saving Mode	H	Power saving Mode

Example:

Computer: QMOD<CRC><cr>

INVERTER: (L<CRC><cr>

Means: the current INVERTER mode is Grid mode.

2.10 QPIWS<cr>: Inverter Warning Status inquiry

Computer: QPIWS<CRC> <cr>

Inverter: (a0a1.....a30a31<CRC><cr>

a0,...,a31 is the warning status. If the warning is happened, the relevant bit will set 1, else the

relevant bit will set 0. The following table is the warning code.

bit	Warning	Description
a0	Reserved	
a1	Inverter fault	Fault
a2	Bus Over	Fault
a3	Bus Under	Fault
a4	Bus Soft Fail	Fault
a5	LINE_FAIL	Warning
a6	OPVShort	Warning
a7	Inverter voltage too low	Fault
a8	Inverter voltage too high	Fault
a9	Over temperature	Compile with a1, if a1=1,fault, otherwise warning
a10	Fan locked	Compile with a1, if a1=1,fault, otherwise warning
a11	Battery voltage high	Compile with a1, if a1=1,fault, otherwise warning
a12	Battery low alarm	Warning
a13	Overcharge	Fault
a14	Battery under shutdown	Warning
a15	Battery derating	Warning
a16	Over load	Compile with a1, if a1=1,fault, otherwise warning
a17	Eeprom fault	Warning
a18	Inverter Over Current	Fault
a19	Inverter Soft Fail	Fault
a20	Self Test Fail	Fault
a21	OP DC Voltage Over	Fault
a22	Bat Open	Fault
a23	Current Sensor Fail	Fault
a24	Battery Short	Fault
a25	Power limit	Warning
a26	PV voltage high	Warning
a27	MPPT overload fault	Warning
a28	MPPT overload warning	Warning
a29	Battery too low to charge	Warning
a30	Reserved	
a31	Reserved	

2.11 QDI<cr>: The default setting value information

Computer: QDI<CRC><cr>

Inverter: (BBB.B CC.C 00DD EE.E FF.F GG.G HH.H II J K L M N O P Q R S T U V W YY.Y X

Z aaa<CRC><cr>

	Data	Description	Notes	Model																						
A	(Start byte																								
B	BBB.B	AC output voltage	B is an Integer ranging from 0 to 9. The units is V.	Default 230.0																						
C	CC.C	AC output frequency	C is an Integer ranging from 0 to 9. The units is Hz.	Default 50.0																						
D	00DD	Max AC charging current	D is an Integer ranging from 0 to 9. The unit is A.	<table border="1"> <tr> <td>PIP-HS 1K</td> <td rowspan="3">20A</td> </tr> <tr> <td>PIP-MS 1K 12V</td> </tr> <tr> <td>PIP-MS 1K 24V</td> </tr> <tr> <td>PIP-HSE 3K</td> <td rowspan="2">25A</td> </tr> <tr> <td>PIP-MSE 3K</td> </tr> <tr> <td>PIP-HS 2K</td> <td rowspan="10">30A</td> </tr> <tr> <td>PIP-HS 3K</td> </tr> <tr> <td>PIP-HS 4K</td> </tr> <tr> <td>PIP-HS 5K</td> </tr> <tr> <td>PIP-MS 2K 24V</td> </tr> <tr> <td>PIP-MS 3K 24V</td> </tr> <tr> <td>PIP-MSX 2K 24V</td> </tr> <tr> <td>PIP-MSX 3K 24V</td> </tr> <tr> <td>PIP-MS 1K 48V</td> <td rowspan="5">15A</td> </tr> <tr> <td>PIP-MS 2K 48V</td> </tr> <tr> <td>PIP-MS 3K 48V</td> </tr> <tr> <td>PIP-MSX 2K 48V</td> </tr> <tr> <td>PIP-MSX 3K 48V</td> </tr> </table>	PIP-HS 1K	20A	PIP-MS 1K 12V	PIP-MS 1K 24V	PIP-HSE 3K	25A	PIP-MSE 3K	PIP-HS 2K	30A	PIP-HS 3K	PIP-HS 4K	PIP-HS 5K	PIP-MS 2K 24V	PIP-MS 3K 24V	PIP-MSX 2K 24V	PIP-MSX 3K 24V	PIP-MS 1K 48V	15A	PIP-MS 2K 48V	PIP-MS 3K 48V	PIP-MSX 2K 48V	PIP-MSX 3K 48V
PIP-HS 1K	20A																									
PIP-MS 1K 12V																										
PIP-MS 1K 24V																										
PIP-HSE 3K	25A																									
PIP-MSE 3K																										
PIP-HS 2K	30A																									
PIP-HS 3K																										
PIP-HS 4K																										
PIP-HS 5K																										
PIP-MS 2K 24V																										
PIP-MS 3K 24V																										
PIP-MSX 2K 24V																										
PIP-MSX 3K 24V																										
PIP-MS 1K 48V		15A																								
PIP-MS 2K 48V																										
PIP-MS 3K 48V																										
PIP-MSX 2K 48V																										
PIP-MSX 3K 48V																										
E	EE.E	Battery Under voltage	E is an Integer ranging from 0 to 9. The unit is V.																							
F	FF.F	Charging float voltage	F is an Integer ranging from 0 to 9. The unit is V.																							
G	GG.G	Charging bulk voltage	G is an Integer ranging from 0 to 9. The unit is V.																							

Communication Protocol

H	HH.H	Battery default re-charge voltage	H is an Integer ranging from 0 to 9. The units is V.	11.5/23/46 for 12/24/48V unit.																										
I	II	Max charging current	I is an Integer ranging from 0 to 9. The units is A.	<table border="1"> <tr> <td>PIP-HS</td> <td>50A</td> </tr> <tr> <td>PIP-MS 1K 12V</td> <td rowspan="5">25A 20A</td> </tr> <tr> <td>PIP-MS 1K 24V</td> </tr> <tr> <td>PIP-MS 1K 48V</td> </tr> <tr> <td>PIP-MS 2K 48V</td> </tr> <tr> <td>PIP-MS 3K 48V</td> </tr> <tr> <td>PIP-HSE 3K</td> <td>50A</td> </tr> <tr> <td>PIP-HSE 5K</td> <td></td> </tr> <tr> <td>PIP-MSE 3K</td> <td>40A</td> </tr> <tr> <td>PIP-MS 2K 24V</td> <td rowspan="2">30A</td> </tr> <tr> <td>PIP-MS 3K 24V</td> </tr> <tr> <td>PIP-MS 4K</td> <td rowspan="7">60A</td> </tr> <tr> <td>PIP-MS 5K</td> </tr> <tr> <td>PIP-MSX 2K 24V</td> </tr> <tr> <td>PIP-MSX 3K 24V</td> </tr> <tr> <td>PIP-MSX 2K 48V</td> </tr> <tr> <td>PIP-MSX 3K 48V</td> </tr> <tr> <td>PIP-MSE 5K</td> </tr> <tr> <td>PIP-MSXE 3K</td> </tr> </table>	PIP-HS	50A	PIP-MS 1K 12V	25A 20A	PIP-MS 1K 24V	PIP-MS 1K 48V	PIP-MS 2K 48V	PIP-MS 3K 48V	PIP-HSE 3K	50A	PIP-HSE 5K		PIP-MSE 3K	40A	PIP-MS 2K 24V	30A	PIP-MS 3K 24V	PIP-MS 4K	60A	PIP-MS 5K	PIP-MSX 2K 24V	PIP-MSX 3K 24V	PIP-MSX 2K 48V	PIP-MSX 3K 48V	PIP-MSE 5K	PIP-MSXE 3K
PIP-HS	50A																													
PIP-MS 1K 12V	25A 20A																													
PIP-MS 1K 24V																														
PIP-MS 1K 48V																														
PIP-MS 2K 48V																														
PIP-MS 3K 48V																														
PIP-HSE 3K	50A																													
PIP-HSE 5K																														
PIP-MSE 3K	40A																													
PIP-MS 2K 24V	30A																													
PIP-MS 3K 24V																														
PIP-MS 4K	60A																													
PIP-MS 5K																														
PIP-MSX 2K 24V																														
PIP-MSX 3K 24V																														
PIP-MSX 2K 48V																														
PIP-MSX 3K 48V																														
PIP-MSE 5K																														
PIP-MSXE 3K																														
J	J	AC input voltage range	J is an Integer ranging from 0 to 1. No unit	Default 0 for appliance range																										
K	K	Output source priority	K is an Integer ranging from 0 to 1. No unit	Default 0 for utility first																										
L	L	Charger source priority	L is an Integer ranging from 0 to 1. No unit	Default 0 for Utility first																										
M	M	Battery type	M is an Integer ranging from 0 to 1. No unit	Default 0 for AGM																										
N	N	Enable/disable silence buzzer or open buzzer	N is an Integer ranging from 0 to 1. No unit	Default 0 for enable buzzer																										
O	O	Enable/Disable power saving	O is an Integer ranging from 0 to 1. No unit	Default 0 for disable power saving																										
P	P	Enable/Disable overload restart	P is an Integer ranging from 0 to 1. No unit	Default 0 for disable overload restart																										

Communication Protocol

Q	Q	Enable/Disable over temperature restart	Q is an Integer ranging from 0 to 1. No unit	Default 0 for disable over temperature restart
R	R	Enable/Disable LCD backlight on	R is an Integer ranging from 0 to 1. No unit	Default 1 for enable LCD backlight on
S	S	Enable/Disable alarm on when primary source interrupt	S is an Integer ranging from 0 to 1. No unit	Default 1 for enable alarm on when primary source interrupt
T	T	Enable/Disable fault code record	T is an Integer ranging from 0 to 1. No unit	Default 0 for disable fault code record
U	U	Overload bypass	U is an Integer ranging from 0 to 1. No unit	Reserved Default 0 for disable overload bypass function
V	V	Enable/Disable LCD display escape to default page after 1min timeout	V is an Integer ranging from 0 to 1. No unit	Reserved Default 1 for LCD display escape to default page
W	W	Output mode	W is an Integer ranging from 0 to 4. No unit	Default 0 for single output
Y	YY.Y	Battery re-discharge voltage	W is an Integer ranging from 0 to 9. The unit is V For LIYUAN MKS Plus LV: The unit is %	13.5/27/54 for 12/24/48V unit. For LIYUAN MKS Plus LV: Default is 90%
X	X	PV OK condition for parallel	X is an Integer ranging from 0 to 1	0: As long as one unit of inverters has connect PV, parallel system will consider PV OK;
Z	Z	PV power balance	X is an Integer ranging from 0 to 1	0: PV input max current will be the max charged current;
a	aaa	Max. charging time at C.V stage	a is an Integer ranging from 0 to 1	0: means automatically

2.12 QMCHGCR<cr>: Enquiry selectable value about max charging current

Computer: QMCHGCR<CRC><cr>

Inverter: (AAA BBB CCC DDD.....<CRC><cr>

More value can be added, make sure there is a space character between every value.

2.13 QMUCHGCR<cr>: Enquiry selectable value about max utility charging current

Computer: QMUCHGCR<CRC><cr>

Inverter: (AAA BBB CCC DDD.....<CRC><cr>

More value can be added, make sure there is a space character between every value.

2.14 QOPM<cr>: Enquiry output mode (For 4000/5000)

Computer: QOPM<CRC><cr>

Inverter: (nn<CRC><cr>

nn:

00: single machine output

01: parallel output

02: Phase 1 of 3 Phase output

03: Phase 2 of 3 Phase output

04: Phase 3 of 3 Phase output

3 Setting parameters Command

3.1 PE<XXX>/PD<XXX><CRC><cr>: setting some status enable/disable

Computer: PE<XXX>/PD<XXX><CRC><cr>

Inverter: (ACK<CRC><cr> if INVERTER accepts this command, otherwise, responds (NAK<cr>

PExxxPDxxx set flag status. PE means enable, PD means disable

x	Control setting
A	Enable/disable silence buzzer or open buzzer
B	Enable/disable overload bypass
J	Enable/Disable power saving
K	Enable/Disable LCD display escape to default page after 1min timeout
U	Enable/Disable overload restart
V	Enable/Disable over temperature restart
X	Enable/Disable backlight on
Y	Enable/Disable alarm on when primary source interrupt
Z	Enable/Disable fault code record

3.2 PF<cr>: Setting control parameter to default value

Computer: PF<CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Communication Protocol

All Inverter parameters set to default value.

x	Parameter setting		
	Parameter	Default value	
1	AC output voltage	230.0V	
2	AC output frequency	50.0Hz	
3	Max charging current	PIP-HS	50A
		PIP-HSE 3K	
		PIP-HSE 5K	
		PIP-MS 1K 12V	20A
		PIP-MS 1K 24V	
		PIP-MS 1K 48V	
		PIP-MS 2K 48V	
		PIP-MS 3K 48V	30A
		PIP-MS 2K 24V	
		PIP-MS 3K 24V	40A
		PIP-MSE 3K	
		PIP-MS 4K	60A
		PIP-MS 5K	
		PIP-MSX 2K 24V	
		PIP-MSX 3K 24V	
		PIP-MSX 2K 48V	
		PIP-MSX 3K 48V	
PIP-MSE 5K			
PIP-MSXE 3K			
	Max utility charging current	PIP-HS 1K	20A
		PIP-MS 1K 12V	
		PIP-MS 1K 24V	
		PIP-HSE 3K	25A
		PIP-MSE 3K	25A
		PIP-HS 2K	30A
		PIP-HS 3K	
		PIP-HS 4K	
		PIP-HS 5K	
		PIP-MS 2K 24V	
		PIP-MS 3K 24V	
		PIP-MSX 2K 24V	
		PIP-MSX 3K 24V	
		PIP-HSE 5K	
		PIP-MSE 5K	
PIP-MSXE 3K			

		PIP-MS 1K 48V	15A
		PIP-MS 2K 48V	
		PIP-MS 3K 48V	
		PIP-MSX 2K 48V	
		PIP-MSX 3K 48V	
4	AC input voltage range	0: Appliance range	
5	Output source priority	0: Utility first	
6	Battery re-charge voltage	11.5/23/46 for 12/24/48V unit.	
7	Charger source priority	0: Utility first	
8	Battery type	0: AGM	
9	Enable/disable buzzer alarm	1: Enable buzzer alarm	
10	Enable/Disable power saving	0: Disable power saving	
11	Enable/Disable overload restart	0: Disable overload restart	
12	Enable/Disable over temperature restart	0: Disable over temperature restart	
13	Enable/Disable LCD backlight on	1: Enable LCD backlight on	
14	Enable/Disable alarm on when primary source interrupt	1: Enable beep on when primary source interrupt	
15	Enable/Disable overload bypass when overload happened in battery mode	0: Disable overload bypass	
16	Enable/Disable LCD display escape to default page after 1min timeout	1: Enable LCD display escape to default page	
17	Output mode	0: single output(for 4K/5K)	
18	float charging voltage	13.5/27/54 for 12/24/48V unit.	
19	Bulk charging voltage	14.1/28.2/56.4 for 12/24/48V unit.	
20	Battery cut-off voltage	10.5/21/42 for 12/24/48V unit.	
21	Battery re-discharge voltage	13.5/27/54 for 12/24/48V unit.	

Note: The correct default value can be gain by QDI command.

3.3 MCHGC<nnn><cr>: Setting max charging current

Computer: MCHGC<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Setting value can be gain by QMCHGCR command.

3.4 MNCHGC<mnnn><cr>: Setting max charging current (More than 100A)

Computer: MNCHGC<mnnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Setting value can be gain by QMCHGCR command.

nnn is max charging current, m is parallel number.

3.5 MUCHGC<nnn><cr>: Setting utility max charging current

Computer: MUCHGC<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Setting value can be gain by QMUCHGCR command.

3.6 F<nn><cr>: Setting Inverter output rating frequency

Computer: F<nn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Set UPS output rating frequency to 50Hz.or 60Hz

3.7 POP<NN><cr>: Setting Inverter output source priority

Computer: POP<NN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Set output source priority, 00 for utility first, 01 for solar first, 02 for SBU priority

3.8 PBCV<nn.n><cr>: Set battery re-charge voltage

Computer: PBCV<nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

12V unit: 11V/11.3V/11.5V/11.8V/12V/12.3V/12.5V/12.8V

24V unit: 22V/22.5V/23V/23.5V/24V/24.5V/25V/25.5V

48V unit: 44V/45V/46V/47V/48V/49V/50V/51V

3.9 PBDV<nn.n><cr>: Set battery re-discharge voltage

Computer: PBDV<nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

12V unit: 00.0V/12V/12.3V/12.5V/12.8V/13V/13.3V/13.5V/13.8V/14V/14.3V/14.5

24V unit: 00.0V/24V/24.5V/25V/25.5V/26V/26.5V/27V/27.5V/28V/28.5V/29V

48V unit: 00.0V/48V/49V/50V/51V/52V/53V/54V/55V/56V/57V/58V

00.0V means battery is full(charging in float mode).

3.10 PCP<NN><cr>: Setting Inverter charger priority

Computer: PCP<NN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Set output source priority:

00 for utility first, 01 for solar first, 02 for solar and utility, 03 for only solar charging

3.11 PGR<NN><cr>: Setting Inverter grid working range

Computer: PGR<NN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set Inverter grid working range, 00 for appliance, 01 for UPS

3.12 PBT<NN><cr>: Setting battery type

Computer: PBT<NN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Set Inverter grid working range, 00 for AGM, 01 for Flooded battery

3.13 POPM<nn ><cr>: Set output mode (For 4000/5000)

Computer: POPM <nn ><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

nn:

00: single machine output

01: parallel output

02: Phase 1 of 3 Phase output

03: Phase 2 of 3 Phase output

04: Phase 3 of 3 Phase output

3.14 PPCP<MNN><cr>: Setting parallel Inverter charger priority (For 4000/5000)

Computer: PCP<MNN><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

00 for utility first, 01 for solar first, 02 for solar and utility, 03 for solar only

M is parallel machine num.

3.15 PSDV<nn.n><cr>: Setting battery cut-off voltage (Battery under voltage)

Computer: PSDV <nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>
 nn.n: 40.0V ~ 48.0V for 48V unit

3.16 PCVV<nn.n><cr>: Setting battery C.V. (constant voltage) charging voltage

Computer: PCVV <nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>
 nn.n: 48.0V ~ 58.4V for 48V unit
 012,013 model: 48.0V~64.0V

3.17 PBFT<nn.n><cr>: Setting battery float charging voltage

Computer: PBFT <nn.n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>
 nn.n: 48.0V ~ 58.4V for 48V unit
 012,013 model: 48.0V~64.0V

3.18 PPVOKC<n><cr>: Setting PV OK condition

Computer: PPVOKC <n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>
 0: As long as one unit of inverters has connected PV, parallel system will consider PV OK;
 1: Only all of inverters have connected PV, parallel system will consider PV OK.

3.19 PSPB<n><cr>: Setting Solar power balance

Computer: PSPB<n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>
 0: PV input max current will be the max charged current;
 1: PV input max power will be the sum of the max charged power and loads power.

3.20 QMN<cr>: Query model name(Just for Hybrid V Series)

Computer: QMN<CRC><cr>

Inverter: (MMMM-NNNN-BB-VV-SSSS<CRC><cr> if Inverter accepts this command, otherwise,
 responds (NAK<cr>

MMMM: model name, NNNN: Rated output VA, BB: Battery voltage, VV: HV/LV, SSSS:
 Special flag

Note: The length of MMMM&NNNN&SSSS may be different for different models

MMMM-NNNN-BB-VV-SSSS list as below:

1	PIP-HSE 5K	
2	PIP-MSE 5K	
3	PIP-HSE 3K	

4	PIP-MSE 3K	
5	PIP-1648MSX (LV)	

3.21 QGMN<cr>: Query general model name

Computer: QGMN<CRC><cr>

Inverter: (NNN<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

NNN: model name number

NNN list as below:

001	PIP-HSE 5K	
002	PIP-MSE 5K	
003	PIP-HSE 3K	
004	PIP-MSE 3K	
005	PIP-1648MSX (LV)	
006	PIP-2424LV-MSD	PIP-2424LV-MSD
007	PIP-2424LV-HS	PIP-2424LV-HS
008	PIP2424MSP	PIP2424MSP
009	PIP2424HSP	PIP2424HSP
010	PIP4024mSP	PIP4024MSP
011	PIP4024HSP	PIP4024HSP
012	PIP5048MS 64V	PIP5048MS 64V
013	PIP5048HS 64V	PIP5048HS 64V
014	PIP5048MS	PIP5048MS
015	PIP5048HS	PIP5048HS
016	ALFA M-5000	ALFA M-5000
017	ALFA P-5000	ALFA P-5000
018	PIP5048MSD/MST	PIP5048MSD/MST

3.22 PBEQE<n><cr>: Enable or disable battery equalization

Computer: PBEQE<n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Enable or Disable battery equalization, n=1 means enable; n=0 means disable;

3.23 PBEQT<nnn><cr>:Set battery equalization time

Computer: PBEQT<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set equalization time, nnn is in the range of 5 to 900minute, every click increase or decrease

5minute.

3.24 PBEQP<nnn><cr>:Set battery equalization period

Computer: PBEQP<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set equalization period, nnn is in the range of 0 to 90day, every click increase or decrease 1day.

3.25 PBEQV<nn.nn><cr>:Set battery equalization voltage

Computer: PBEQV<nn.nn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set equalization time, nn.nn is in the range as below.

VP5000 and VM5000: 48.0~61.0V;

VP3000 and VM3000 and VM-3000 PLUS: 24.0~31.5V;

3.26 PBEQOT<nnn><cr>:Set battery equalization over time

Computer: PBEQOT<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Set equalization time, nnn is in the range of 5 to 900minute, every click increase or decrease 5minute.

3.27 PBEQA<n><cr>: Active or inactive battery equalization now

Computer: PBEQA<n><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<cr>

Active or inactive battery equalization now, n=1 means active; n=0 means inactive;

3.28 QBEQI<cr>: Battery equalization status parameters inquiry

Computer: QBEQI <CRC><cr>

Inverter: (B CCC DDD EEE FFF GG.GG HHH III J KKKK <CRC><cr>

	Data	Description	Notes	Model
--	------	-------------	-------	-------

Communication Protocol

a	(Start byte		
b	B	Enable or Disable equalization	B is an Integer number 0 to 1..	
C	CCC	equalization time	C is an Integer number 0 to 9. The unit is Minute.	
D	DDD	equalization period	D is an Integer number 0 to 9. The unit is day.	
E	EEE	equalization max current	E is an Integer number from 0 to 9. The unit is A.	
F	FFF	reserved	reserved	
G	GGGG	equalization voltage	G is an Integer ranging from 0 to 9. The units is V.	
H	HHH	reserved	reserved	
I	III	equalization over time	I is an Integer ranging from 0 to 9. The unit is Minute.	
j	J	equalization active status	J is an Integer ranging from 0 to 1.	
k	KKKK	reserved	reserved	

3.29 PCVT<nnn><cr>: Setting max charging time at C.V stage (For 4000/5000, and 012, 013

model)

Computer: PCVT<nnn><CRC><cr>

Inverter: (ACK<CRC><cr> if Inverter accepts this command, otherwise, responds (NAK<CRC><cr>

Setting value can be gain by QMCHGCR command.

nnn is max charging time at C.V stage, the range is from 000 to 900 but in multiples of 5. 000 means automatically.

4 Appendix

4.1 CRC calibration method



CRC. c